




Lite



# Instruction Manual

Issued by SweTrack Electronics AB  
Version 2.1 2021-10-22

# Preface

---

Thank you for purchasing a SweTrack Lite!

This instruction manual describes how to get started with your new product, as well as getting acquainted with the product's exterior features. Please read this instruction manual carefully before commencing use of the product. More information can be found in our Online Support Center, which is accessible at [www.swetrack.com/support](http://www.swetrack.com/support).



# Installing the device

---

The SweTrack Lite is designed to connect directly to the electrical system of your vehicle. SweTrack Lite works with power systems between 9 and 36 volts. If you are unsure how to install the product, contact a specialist. Swe Track accepts no liability for damage to product or property resulting from improper installation.

1

## Connect the device to the wiring

---

In the product's box you will find a set of wires that are used to connect the SweTrack Lite device to the vehicle's electrical system. Connect the wires to the device using the round plug located on the wiring and the device.



2

## Connect the device to the vehicle's power system

---

Connect the black cable to a negative terminal, and the red cable to a positive terminal. The orange cable can be connected to the ignition switch of the vehicle, which allows you to receive notification when the ignition of the vehicle is turned on or off. However, using this cable is optional and is not required for the product to work.

3

## The device is now ready for use

---

When you have installed the device in your vehicle, the device is ready to start communicating with you. However, you need to download the app and activate a data plan a before you can begin using the product

# Getting started with the app

---

SweTrack Lite is controlled through the SweTrack Live app. In the SweTrack Live app, you can see the device's current location, enable geofences, request location history, and more.

## 1 Download the app

---

Visit the App Store (iOS) or Google Play (Android) and search for SweTrack Live. The app is free.

## 2 Create an account

---

Once you've started the app, select **Sign up** found at the bottom of the login screen. Then fill in your name, your email address and choose a password. Finally, you need to enter the device's IMEI number. The easiest way to do this is to click the **Scanner** button and hold the phone's camera against the IMEI barcode on the back of the product. You can also select **Text** and enter the IMEI number manually.

Once you have filled in all fields, click the button **Create Account**. You then log in with your email address and the password you chose.

## 3 Use SweTrack Live from a computer

---

SweTrack Live can also be used from the browser on a PC or Mac. To visit SweTrack Live from your computer, go to [www.swetrack.com/live](http://www.swetrack.com/live) in your browser. You use the same login information on the computer version as in the mobile app.

# Activating a data plan

---

SweTrack Lite requires an active data plan for mobile data traffic to work. The data plan includes unlimited tracking across Europe. Without mobile data, the product can not communicate with the Internet and transfer its position data to you

1

## How to start a data plan?

---

1. Go to the web app [www.swetrack.com/live](http://www.swetrack.com/live) and log in to your account. If you do not have an account, click on "Sign up", follow the instructions and then log in.
2. Go to the **"Data Plans"** page and click on **"My Cards"**.
3. Click on **"Add card"** and then fill in your card details. Then click on the blue **"Save"** button.
4. Then click on the **"Devices without data plan"** tab.
5. Select the device or devices for which you want to create a data plan and then click on **"Create a data plan"**.

2

## Cancel a data plan

---

1. Go to the web app [www.swetrack.com/live](http://www.swetrack.com/live) and log in to your account.
2. Go to the **"Data Plans"** page and click on **"Devices with data plan"**
3. Select the devices you want to cancel a data plan, and then click **"Cancel data plan"**

The data plan / data plans will now be cancelled and not renewed until you choose to reactivate them by going to the tab **"Devices without data plan"** and clicking **"Activate data plan"**.



**Important notice:** Never perform unauthorized modifications to the device, such as replacing the built-in SIM-card with another SIM-card. The device only works with the factory installed SIM-card. Also, do not install the built-in SIM-card into other equipment, the SIM-card will be permanently blocked and rendered unusable, even if it is reinstalled in the SweTrack device. Unauthorized modifications can damage the product and will cause the one-year factory warranty to be permanently invalidated.

# Using the Mobile App

---

Once you have created an account and activated a subscription, the product will start to work within about 20 minutes. You will then be able to see it on the map in the SweTrack Live app or via a computer by going to [www.swetrack.com/live](http://www.swetrack.com/live).

The product's position is automatically updated every 15 seconds when the product is in motion. Keep in mind that the product is, by default, only active when the built-in vibration sensor notes movements. If you do not see the product on the map in the app, you may therefore need to shake it a little so that it starts up.

In the app, in addition to displaying the current position, you can also change the device settings and activate different types of alarms.

# Power saving mode

---

By default, the product is registered to only search and report position data to the app when it is in motion. However, other functions, such as mobile antennas, are turned on. This setting is called standard power saving mode. With this mode, you can change settings at any time as the product is always connected to the network, but it only searches for new positions as it moves.

You can also activate an aggressive power saving mode, which means that all functions are switched off when the product is stationary. This saves a lot of power, but it also means that any settings you change do not take effect until the product wakes up. It is also possible to deactivate all energy saving functions. This means that the product also reports position data when it is stationary. This suits you who need continuous updating about the product's position even when the object is stationary, but this consumes more battery.

## 1

### Edit your power saving mode

---

Start by first navigating to **My Devices** that you reach by tapping the icon on the far left in the lower navigation menu.

Here you get a list of all the devices that you have added to your account. Select device by tapping the arrow icon to the right of the device name. This will open the device settings.

By pressing **Power Saving Mode**, you open a pop-up with different options for Power Saving modes. The switch that is activated will be marked blue.

Select an option by tapping the corresponding switch and then save by clicking on **Save**.

# Warranty & Service Information

---

This page contains information about our warranty and service terms.

1

## Support & Service

---

You'll find answers to the most common questions about our products and services in our Support Center, located at [www.swetrack.com/support](http://www.swetrack.com/support). If you can not find the answer to your question in this manual or in the support center, contact our customer service at [support@swetrack.com](mailto:support@swetrack.com).

2

## Privacy Policy

---

We at SweTrack take the integrity of our customers seriously, and we never share personal data or information about how the product is used with any third party. You can find our full privacy policy by going to the page [privacy policy](#).

3

## Hardware Warranty

---

SweTrack provides a one year hardware warranty on all products to all customers. The warranty covers original hardware defects and does not cover software failures or errors resulting from external damage and / or improper handling of the product.

# Contact information

If you can not find the answer to your question in this manual or in the support center, contact our customer service at [support@swetrack.com](mailto:support@swetrack.com).